



Severosklo Kamenický Šenov s.r.o.
sídlo: Stará huť 129, 471 14 Kamenický Šenov
IČ:254 11 560; DIČ:CZ25411560, spisová zn. C 16276, Krajský soud Ústí nad Labem

User manual

PROSVAR, cover visor of clear glass

Type: PROSVAR cover visor without filtering effect made of clear glass - type No. 1

Protective shields are manufactured and supplied by: **Severosklo Kamenický Šenov s.r.o.**
Stará huť 129
47114 Kamenický Šenov

phone: 487764082-3

e-mail: severosklo@severosklo.cz

www.severosklo.cz

Protective lenses are made of enamel. PROSVAR cover visor made of clear glass, type: PROSVAR cover visor without filtering effect made of clear glass - type No. 1 is intended for basic use, with a guarantee of minimum strength. Optical Class 1 without filtering effect and without corrective effect. Lenses are designed to protect the vision from dirt in the surrounding environment and from scratches. This visor must only be used with a protective filter.

The product is effective and complies with the conditions of European Parliament and Council Regulation (EU) 2016/425, ČSN EN 166:2002/rev. 1:2010, and ČSN EN 169:2002. Classification of personal protective equipment: PROSVAR cover visor made of clear glass, type: PROSVAR cover visor without filtering effect made of clear glass - type No. 1 classified by the manufacturer as OOP category II.

EU declaration of conformity can be found at web site: www.severosklo.cz.

Notified Body involved in OOP assessment: Institute for Testing and Certification, a.s. (NB 1023) with registered office at třída Tomáše Bati 299, Louky, 763 02 Zlín.

PROSVAR glass are marked with the following (example of marking):

SCS CE

which is located in the upper right corner of the rectangular shield or on the edge of the round shield, and is in white colour.

Meaning of marking	SCS	- manufacturer identification mark
	CE	- conformity marking

The protective lenses are made of glass with a smooth surface. Glass is an inert material to the work atmosphere and is resistant to commonly used liquids and cleaning agents without releasing any harmful substances and decomposition intermediates. The shields are inserted into a hood or glasses frame during use, so there is no risk of injury from the edges of the shield. The protective lenses are manufactured in such a way they do not exhibit optical distortions during use. The relevant dioptric effects are given in ČSN EN 166.

Disinfection and cleaning can be carried out using water and common disinfectants and cleaning agents intended for window glass cleaning. Cleaning must not be carried out in a dishwasher.

Usability when adhering to normal usage guidelines is 10 years. In case of damage (scratching, breaking), the eyepiece must be replaced. Eyepiece may be damaged due to a fall from a height or a large mechanical impact that exceeds normal usage.

Eyepieces are packaged in cardboard boxes of 50 or 100 pieces, with a marked expiration date.



Severosklo Kamenický Šenov s.r.o.
sídlo: Stará huť 129, 471 14 Kamenický Šenov
IČ:254 11 560; DIČ:CZ25411560, spisová zn. C 16276, Krajský soud Ústí nad Labem

Storage of eyepieces must be done in a dry environment.

Disposal is carried out by placing them in recycling containers intended for clear glass waste

Date and place of issue:
Kamenický Šenov 30.1.2023

Sign and stamp